

ROOM MAKER WALLBED REMOVAL

Use attached diagram.

- Step 1** Remove the headboard/padboard assembly.
- Step 2** For safety reasons use two (2) men. One man should climb inside the bed recess while the second man holds the bed relatively upright on the outside to keep the bed from falling as **Step 3** occurs.
- Step 3** The man on the inside should loosen the four (4) "hinge spring adjusting nuts" (indicated on the diagram) as loose as possible *without removing them*. The man outside supporting the bed relatively upright will not only keep the bed from falling but make the nuts easier to loosen as that process continues.
- Step 4** When the four (4) adjusting nuts are fully loosened (not off), lay the bed to the floor.
- Step 5** Remove the nuts from the eight (8) "hinge weldment carriage bolts," four (4) on each side (see diagram). Lift the hinges and bed from the baseplate and the bed will be free from the floor.

The plywood baseplate can be removed by taking the nuts off the six (6) baseplate anchor bolts (see diagram) and lifting off.

TOOLS REQUIRED

- Phillips screwdriver
- Large flat-blade screwdriver
- Utility knife
- Electric drill (3/8")
- A 1" drill bit may be required (see page 5)
- Rotary hammer drill and 1/2" bit – optional
- Masonry bit (if attaching to masonry floor or wall); size of bit depends on floor type - refer to pages 4 - 5
- Tape measure
- Pencil
- Carpenter's level
- Hammer
- Vise-grip pliers
- Pliers
- Ratchet wrench
- 9/16" and 3/4" deep sockets
- 6" socket extension
- Open-end wrenches: 7/16" (qty 2); 9/16"; 3/4"; 15/16".

UNPACKING

1. Remove the steel bands and open the carton.
2. Remove the main frame and place it on the floor with the face panel facing down (be sure there is nothing on the floor which could scratch the bed face).

⚠ CAUTION

To avoid damaging the unit, do not walk on the bed's face panel!

If the bed was ordered without a factory-finished face panel on the main frame, you can attach paneling or other covering either while the frame is still on the floor or after the bed is in the recess. Refer to the separate instructions which are included in the small parts pack.

3. King bed frames are shipped in two sections which must be bolted together. Refer to page 7 for an illustration of the parts.
4. Unpack the headboard, padboard, baseplate, mattress strap, handle package, and any other items which may be stapled to the carton. Refer to the illustration below, or to the Parts List drawing on page 17, to identify the various parts.
5. Open the separate carton which contains the power packs (hinge weldments and spring tubes) and the headboard supports.

